

PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

PART # WK601-34 SUZUKI SAMURAI

THIS KIT IS FOR THE FOLLOWING APPLICATIONS: SAMURAI 1300cc 1987-1990

Thank you for purchasing a Performance carburetor conversion kit. Our kits are designed to unleash the performance potential of your engine but not at the cost of reliability and fuel efficiency.

This installation guide covers vehicle preparation, old carburetor removal, carburetor installation, and new carburetor adjustments. A trouble-shooting guide is supplied if needed.

Before installation please read this guide thoroughly and if you have any questions please call our Toll Free Technical Line at 1 (800) 871-3405.

Any items in BOLD FACE TYPE or with a  next to it, Please pay extra attention to. This will help to ensure an error free installation with optimal vehicle operation.



THIS CARBURETOR CONVERSION KIT INCLUDES:

**34 DGEC CARBURETOR
MANIFOLD BASE ADAPTER
LINKAGE KIT
HARDWARE KIT
CHROME AIR CLEANER**



The Following is a List of the Tools that will be needed to install this conversion kit:

- Metric Socket and Wrench Set
- Metric Allen Key Set
- Screwdrivers
- Pliers (needle nose)
- Gasket Scraper
- Wire Brush

The Following is a list of supplies that are needed to install this conversion kit:

- Carburetor Cleaner
- Clean Rags
- Engine Cleaner
- Aluminum Foil
- Tags (these are needed to label hoses etc.)

The Following is a list of optional items that are very helpful in installing this conversion kit:

- Vacuum Gauge/ Tester
- Fuel Pressure Gauge/ Tester
- Flashlight
- Magnet
- Vehicle Shop Manual

Legal in California only on racing vehicles which may never be driven on a highway.

PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

FOR SAFETY PURPOSES:

- **USE CLAMPS ON ALL FUEL HOSES.**
- **DO NOT USE GASKET SEALERS, USE GASKETS PROVIDED.**
- **WHEN REMOVING OLD CARBURETOR LABEL ALL HOSES AND WIRES.**
- **IF NECESSARY CLEAN ENGINE BEFORE INSTALLATION.**
- **USE LOCTITE ON HARDWARE INSIDE AIR CLEANER AND INTAKE MANIFOLD STUDS.**
- **IF REWIRING IS NEEDED ALWAYS USE AN INSULATED CONNECTOR OR TAP.**
- **NEVER ALLOW DIRT IN THE CARBURETOR.**
- **DO NOT OVERTIGHTEN JETS OR THROTTLE LINKAGE.**
- **NEVER OPERATE THE ENGINE WITHOUT A FUEL FILTER.**
- **DO NOT ALLOW FUEL TO SPILL OR LEAK.**
- **BE CAREFUL NOT TO CUT OR DENT THE ALUMINUM GASKET SURFACES OF THE INTAKE MANIFOLD OR CARBURETOR.**
- **ALWAYS WEAR EYE PROTECTION.**

This section should be completed before you install this Conversion Kit.

- Please make sure that the Parts were not damaged in shipment.
- Please check the contents of the kit against the list on page 1.
- If any parts were missing or the parts were damaged in shipping please contact your Dealer.
- Verify that your vehicle had a recent tune up and you do not have any other mechanical problems. The Carburetor can not fix engine and ignition problems.
- Carburetors require 3.5 p.s.i. of Fuel pressure. If your fuel pressure is more than 3.5 p.s.i, obtain a Fuel Pressure Regulator from your Dealer.



YOU SHOULD HAVE NO EXHAUST GAS LEAKING FROM THE EGR.



- Carburetors are preset at the Factory.
Only make adjustments to the carburetor after the installation, and running the vehicle for the first time.
After the carburetor is installed record the factory settings if needed in the future.
- Please save your sales receipt and all carburetor documentation for future use.

Any items in **BOLD FACE TYPE** or with a  next to it, Please pay extra attention to. This will help to ensure an error free installation with optimal vehicle operation.

PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

REMOVAL OF OLD CARBURETOR

- Remove the Battery's negative cable.
- Take off the original Air Cleaner Assembly.
- Remove the Fuel Supply hose that is attached to the carburetor and label it.
- Remove the Fuel Return hose and plug it.
- Remove and label the vacuum hoses connected to the carburetor.
- Remove and label all of the electrical connectors attached to the carburetor. Identify the electric choke wire.
- Remove the Float bowl Vent hose and plug it.
- Remove and label all electrical and vacuum connections to the vacuum switching valves and remove them along with the vacuum manifold.
- Remove the PCV hose from the Carburetor.
- Remove the water hoses from the choke thermostat and their sources on the intake manifold. Take the supplied hose and run this hose from one water outlet on the intake manifold to the other. This carburetor has an electric choke and you will not be using the water choke lines.
- Remove carburetor and all spacers and gaskets from the intake manifold. Place a clean rag in the intake opening to keep dirt and tools etc. out.



DO NOT FORGET TO REMOVE THE RAG BEFORE INSTALLING THE CARBURETOR



- Remove the manifold studs from the intake manifold. Double nut each stud to remove.



DOUBLE NUTTING MAY RUIN THE NUTS BUT WILL NOT DAMAGE THE STUDS



- Remove any excess gasket material from intake manifold. You can use a gasket scraper, wire brush and carburetor cleaner.



DO NOT USE A WIRE WHEEL OR ANY POWER TOOLS AS THEY MAY DAMAGE THE MANIFOLD





CARBURETOR INSTALLATION

- Remove the adapter plates, gaskets and hardware from the packaging
- Mount the first adapter and gasket to the intake manifold making sure that the allen head bolts are flush. Mount the top adapter and gasket to the bottom adapter plate.

Any items in **BOLD FACE TYPE** or with a  next to it, Please pay extra attention to. This will help to ensure an error free installation with optimal vehicle operation.

PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

WEBER CARBURETOR INSTALLATION (continued)

- Install the Carburetor on the four mounting studs. Take the linkage arm out of the hardware bag and install on the back two studs on the carburetor . Using a criss-cross pattern tighten all four nuts evenly Fuel Inlet Faces back of Vehicle.  **DO NOT OVERTIGHTEN** 
- Install throttle cable into the bracket but do not tighten the cable all the way.
- Take the throttle cable and cut the lug off of the end. Cut as close to the lug as possible.
- Take the throttle stop and clip and install on the throttle lever that is on the carburetor (see picture).
- With an assistant in the vehicle depress the accelerator and adjust until you achieve full throttle. Once full throttle is achieved tighten the screw in the cable stop and throttle cable in the throttle cable bracket. A return spring is supplied if needed(see pictures for installation).
- Locate the fuel inlet pipe (see picture) on the carburetor and connect the supply line to it.
- Locate the vacuum advance hose and connect it to the vacuum advance port on the carburetor.
- Locate any open vacuum ports and hoses and plug them. (check local laws)
- At this point make sure that all hose clamps are tightened and that all of the electrical connectors are connected and insulated
- Reconnect the Battery's negative cable

Any items in **BOLD FACE TYPE** or with a  next to it, Please pay extra attention to. This will help to ensure an error free installation with optimal vehicle operation.

PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

CARBURETOR INSTALLATION (continued)

- Crank Engine without starting and check for fuel leaks.



DO NOT GO ANY FURTHER WITHOUT INSPECTING AND FIXING



- Remove Air cleaner from packaging. Connect plastic breather tube to air filter base then bolt air filter base to carburetor using the four screws provided.
- Attach the breather hose from the valve cover to the air cleaner.
- Put the air filter element on the air filter base and attach the air cleaner top with the clips provided.
- To check the clearance between the hood and air filter, place some crumpled up aluminum on the air cleaner top and slowly lower the hood and check clearance.

CARBURETOR ADJUSTMENTS (see pictures for identification of components)

- Only make the adjustments discussed here if necessary.
- To set the idle speed make sure that the engine is warm, set the speed to the vehicle manufacturer's setting. To raise the speed turn the idle screw (clockwise) in, and to lower the speed turn the speed screw (counter clockwise) out.
- To set the idle mixture turn the idle mixture screw in slowly (clockwise) counting the amount of turns you make until the idle speed drops off. Turn the screw out (counter clockwise) counting the turns until the idle drops off again. Turn the screw now back in half the distance that you turned out. Now the mixture is set.
- To set the fast idle make sure that the engine is cold. Press the accelerator pedal to the floor and let go. Start the engine (do not touch the accelerator pedal once you touch the accelerator after the engine is running the fast idle cam is disengaged. The engine should be revving between 2000 and 2500 Rpm's. Turn off the engine. To adjust the fast idle speed turn the fast idle screw in (clockwise) to increase engine RPM, to decrease engine RPM turn the fast idle screw out (counterclockwise) Do not touch the accelerator and restart engine to check RPM.
- The choke is Factory set. To adjust make sure that the engine is cool (below 68F) Turn the throttle linkage all the way to set the choke. The plates should be closed. Make a mark on the plastic choke cap and the carburetor where the two surfaces meet. Loosen the three screws one turn. Hold the throttle about one third open and start to slowly turn the cap 1/8" (you should feel the spring tension in the choke tightening). Retighten the three screws (do not over tighten). You may now have to go back and check the fast idle speed and adjust if necessary.

Any items in **BOLD FACE TYPE** or with a  next to it, Please pay extra attention to. This will help to ensure an error free installation with optimal vehicle operation.

PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

TROUBLE SHOOTING GUIDE

In order to properly trouble shoot any suspected carburetor problems please double check the following:

Please read through the Carburetor Installation section. Go over any item that has **BOLD FACE TYPE**

Or has a  next to it.

If the vehicle will not start please check the following:

Check that the fuel pump is functioning properly. Check with pressure gauge.

Make sure that the ignition system is functioning properly.

If the engine idles too fast or too slow or stalls please check the following:

Make sure that you have no vacuum leaks. You should check all engine vacuum line connections and at the carburetor base (including the adapter plates).

Check all Carburetor adjustments. Idle mixture, idle speed, and fast idle. In this order.

Check that the idle cut-off solenoid is working. You can check this by listening for a clicking noise coming from the solenoid when the key is turned on or off.

If the engine idles fine but acts as if it is running out of fuel when driving please check the following:

If new fuel filter was not installed install one now. The old fuel filter may be clogged.

Check that the fuel pump is functioning properly. Check with pressure gauge.

Check all fuel lines. Make sure that the lines are not pinched or kinked.

Check that the vehicle has not run out of gas.

Check the fuel tank venting system. (Refer to vehicle shop manual)

If the engine runs rough or sounds like it is missing at idle please check the following:

Make sure that you have no vacuum leaks. You should check all engine vacuum line connections and at the carburetor base (including the adapter plates).

Check the idle mixture adjustment.

If you were not able to correct the problem with the information provided above contact your Dealer or call our Toll Free Techline line at 1 800 871 3405.

 **Also please remember that any additional engine modifications such as Headers, Hi Performance camshafts, free flow exhaust systems may require that the carburetor be recalibrated.**


If this is the case please contact your Dealer or call our Toll Free Techline line at 1 800 871-3405.

Any items in BOLD FACE TYPE or with a  next to it, Please pay extra attention to. This will help to ensure an error free installation with optimal vehicle operation.


PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

34 DGEC CARBURETOR

Picture 1A




Picture 2A




PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE

Installation Views on the Vehicle.



Installed on Vehicle




Linkage installation shown

PERFORMANCE CARBURETOR CONVERSION KIT INSTALLATION GUIDE



Breather Line

Fuel inlet



Vacuum Advance

Electric Choke